



Bracing must be installed on every second bay on the run

- 1** Insert shelf clips at mid-height on both side panels. Once the shelf clips are inserted, slot the shelf over the clips. The first shelf should be mid-height so to ensure the bay is stabilised throughout assembly.
- 2** Install the top and bottom shelves by inserting the shelf clips in the same way as in step 1. The shelf clips are positioned at the very top and very bottom holes on the shelf panels.
- 3** Attach top and bottom cross braces using M6 mushroom head bolts and nuts. Insert the bolts from the inside of the bay. Top bracing starts at the 2nd hole from the top, the bottom bracing starts at the 2nd hole from the bottom.
- 4** Attach the rest of the shelves at desired heights, again by first inserting the shelf clips to both side panels.
- *5** If building a run of bays, the next bay connects its shelves to the existing shelf clips on the side panel of the existing bay.

Safety Precaution

Requires two people wearing safety gloves, shoes and glasses

Tools required

Wide flat head screwdriver,
Spanner 10mm