



1. Attach plastic feet to the uprights
2. Attach the horizontal battens to join the uprights together and push lug in using the flathead screwdriver, repeat for the second frame.
3. Insert shelf clips at desired heights to position the shelves.
4. Place top and bottom shelves onto the clips.
5. Attach the cross bracing at the back of the bay using the expo spanner + 8mm spanner.
6. Insert the remaining shelves onto the shelf clips to complete the bay.
7. To add an extension bay, repeat steps 1, 2 and 3 for one frame, insert shelf clips at the desired height into the outside of the existing bay. Repeat steps 4 and 6.

Expo 4 Shelf Capacities

| Width (mm) | Depth (mm) | | | |
|------------|------------|-------|-------|-------|
| | 300 | 400 | 500 | 600 |
| 700 | 140kg | 130kg | 200kg | 180kg |
| 1000 | 110kg | 200kg | 180kg | 200kg |
| 1150 | 90kg | 180kg | 150kg | 150kg |

Tools Required

Rubber Mallet, Flat Head Screw Driver
Expo Spanner (included), Spanner 8mm

Safety Precaution

Two competent people wearing **safety gloves**, **safety shoes** and **protective eyewear** are recommended to undertake the assembly.

scan for more info